



This document was formerly published as GEX Doc. No. 100-251 *Dosimeter Measurement Competence*

1 - Purpose

To provide guidance for evaluating the competency of a person measuring dosimeters on the DoseControl Dosimetry System.

2 - Scope

A formal competency test should be performed for any person measuring dosimeters where the data will be used to make further decisions about process or product.

3 - General Information

It is recommended that persons that do not have experience with the measurement system should prove to themselves and document a test for the repeatability of measurement of the same sample is within expected limits. Annual retesting of employees who often measure dosimeters should also be considered.

Acceptance criteria is based on the characterization and validation of the DoseControl Dosimetry System completed and on file at GEX Corporation.

The procedure can be used for GEX B3, FWT, Harwell Red and Amber PMMA, and CTA film dosimeters.

4 - Procedure

- 4.1 Prerequisite – IQ and OQ (or equivalent) have been completed for the dosimetry system.
- 4.2 Testing may be completed using either the Thermo software or using GEX DoseControl software as the software has no influence on the test result.
- 4.3 Testing should be completed for each dosimeter holder type that the person will utilize.
- 4.4 Select a dosimeter sample of each type to be tested that has an approximate absorbance value of 0.300 or higher.
- 4.5 Inspect the dosimeter and ensure that the surface of the dosimeter is clean and undamaged. A damaged or dirty dosimeter film may skew the test result.
- 4.6 Initialize (power on/power cycle) the instrument prior to testing and warm up the instrument (if required) per the documented operational instructions from GEX (see *Related Documents*).





- 4.7 Open the sample compartment lid and insert the dosimeter holder component that snaps into the GEX baseplate and visually confirm the holder is fully seated / installed correctly.
- 4.8 Insert the dosimeter into the holder and execute the first measurement.
- 4.9 Remove the dosimeter from the holder and then reinsert the dosimeter into the holder again. Execute the second measurement.
- 4.10 Repeat the process to accumulate 30 measurements for the single dosimeter.
- 4.11 Analyze the data (see the example of one data analysis concept using MS Excel).
 - 4.11.1 The C.V.% should be less than 0.4 or else the system is not installed and operating correctly, or the user is negatively influencing the results due to technique. Retrain and test again.
- 4.12 The dosimeter may be discarded upon completion of testing.



5 - Example of a Measurement Competency Data Analysis Form



	A	B	C	D
1				
2	Technician Name:			
3	Date Measured:			
4	Spectrophotometer ID:			
5	Dosimeter Holder Type:			
6	Dosimeter Type:			
7				
8	Reading		Irradiated	
9	Number		Dosimeter	
10	1			
11	2			
12	3			
13	4			
14	5			
15	6			
16	7			
17	8			
18	9			
19	10			
20	11			
21	12			
22	13			
23	14			
24	15			
25	16			
26	17			
27	18			
28	19			
29	20			
30	21			
31	22			
32	23			
33	24			
34	25			
35	26			
36	27			
37	28			
38	29			
39	30			
40				
41	Average		=AVERAGE(C10:C39)	
42	Std Deviation		=STDEV(C10:C39)	
43	C.V. (%)		=C42/C41*100	
44				
45	Circle One:		PASS/FAIL	
46	Performed By & Date:			
47	Reviewed By & Date:			
48				





Disclaimer - The information contained in this document is provided "as is" and is not a substitute for the user's professional judgement. It is provided as a convenience to those using products provided by GEX Corporation who have sufficient technical skills to evaluate and properly apply the information in this document. It is the responsibility of the user of this document to ensure that the information in this document, and the use of such information, is accurate, complete, applicable to the product, suitable for the user's purposes, and in compliance with all laws and regulations. GEX Corporation believes the information provided in this document is accurate and reliable as of the time of writing, but it undertakes no obligation to update or correct this document. GEX Corporation may, but is not required to, make changes to this document at any time without notice. By using the information in this document, the user represents and warrants that he or she has the skills necessary to properly understand and apply this information and that he or she will comply with all applicable laws and regulations including, without limitation, those relating to medical devices, pharmaceutical products, or other applicable industries. The user assumes all risks associated with using this information and any results or output resulting from the application of this information to GEX Corporation's products. The user agrees not to hold GEX Corporation liable for any errors or omissions contained within.